



American Energy Systems Inc ***Information Bulletin***

Installing Legs on a Magnum Baby Countryside Unit

NOTE: BE SURE THE STOVE IS TURNED OFF, AND THE UNIT IS COLD BEFORE INSTALLING LEGS.

TO INSTALL LEGS ONTO MAGNUM BABY COUNTRYSIDE UNIT:

- A. Carefully tip unit onto back.
- B. Using the mounting pads and diagram shown below, position pads as shown.
- C. With a .281 diameter drill bit, drill a hole through bottom of the base....make sure not to drill though the power supply on the DC units.
- D. Mount the legs with the 1/4-20 x 2 1/4" hex bolt supplied by AES through the leg, pad and the base as shown.

