

HOW TO APPLY DLETE ACTIVE ODOR ELIMINATOR INSIDE AN AUTOMOBILE OR TRUCK

1. The car should be thoroughly cleaned of all debris, grime, etc.
2. Start the car. Turn on the air conditioning full blast with recycle mode on.

(this is the recirculation mode where it's just recirculating the air inside the cabin instead of pulling in air from the outside.)



3. Spray the entire car, covering all surfaces including the roof liner.
4. Spray liberally under the dash in front of the passenger seat. This is where the cabin air intake is located.

(note: the cabin air filter should be replaced with a new one. Many odors are trapped in this filter. Follow the car manual for instructions. If a new one is unavailable, at a minimum you must remove the air filter, clean and spray it liberally with DLETE and allow it to air dry.)

5. Run the car with doors closed for 15 minutes.
6. Leave the car fan on high speed, but now turn off recycle mode.



7. While the car is running, spray or pour a liberal amount into the exterior air intake vent. Generally, this is located on most cars right below the windshield. Some models require the hood to be open.
8. Run the car for 15 minutes in this mode.
9. If odors persist, note that it can sometimes take several hours for the probiotics to remove embedded odors. In the most extreme conditions, after 48 hours repeat this application.