

# NEW RAGE CYCLES

## INSTALLATION INSTRUCTIONS

### DUCATI HYPERMOTARD 821

#### 'BLACKOUT' FRONT SIGNALS

- 1 On back of handguard, remove Philips head screw and take off stock lens
- 2 Unplug wires from stock lens
- 3 With NRC blinker, slide wires through handguard, plug into OEM spade connectors, and shrink tube
- 4 Take provided hardware and mount signals