NEW CLES INSTALLATION INSTRUCTIONS

KTM RC8

FENDER ELIMINATOR

- (1) Remove seat
- 2 Unplug connector underneath seat (picture 1)
- Unbolt (4) M5 bolts with 8mm socket, and remove stock stalk (picture 2)
- To finish removing stock harness, remove (10) T20 bolts and open stalk (picture 3)
- Unplug (2) white connectors, and slide license plate light bulb out (picture 4)
- 6 Remove bulb from license plate light
- Plug back in connector, previously disconnected in step 2 (picture 5)
- Before mounting NRC kit onto your bike, slide M6x25 bolts through plate, sandwiching supplied push nuts between 3/8" spacers and bolts, holding the bolts in place (picture 6)
- Feed all connectors through the hole up underneath seat and mount the kit using supplied bolts (picture 7)
- 10 Mount your license plate to the tabs on the bracket











NEW COLES INSTALLATION INSTRUCTIONS

FENDER ELIMINATOR

- (1) Remove relay harnesses from hardware bag (picture 8)
- Plug in plate light connectors into plate light housing (picture 9)
 - Red NRC wire to White wire on RC8
 - Black NRC wire to Brown wire on RC8
- Plug in the rest of the connectors (Picture/Arrows 10)
- Test your connections and make sure your blinkers flash correctly (RH/LH)
- 12 Put seat back on your bike









