
Instructions for assembling Layzee Living Timber Decking Kit.

1. Unscrew 90mm packers from metal brackets and discard.
2. Screw the joist hangers onto the frame in the locations that have been marked out and pre-drilled for you
3. Slot the internal joists into joist hangers and place one on each end of the frame and screw together with 100mm screws supplied, internal joists fix into the hangers, the end joists are simply screwed through the timber and into the end of the joist/ frame.



Joist hanger view

4. If your decking is 5.4m or longer it will be in two sections so repeat step 2.



What the completed frame should look like

5. If deck is 5.4m or longer and both frames are now ready to join together place end to end and screw together with screws supplied, so you know which sides go together joist hangers would be back-to-back.

For all your garden luxuries...



6. Lay out the black weed membrane and lay frame down on it to secure



7. Now level your deck and with a tape, measure corner to corner and make sure deck is square.
8. Place first deck board in position flush with edge of decking, we advise that you pre drill just the ends of the decking so when screws go in you don't split the timber; 2 green decking screws per joist.
9. Leave a 5mm approx. gap between each board and start to fix moving down the length of the frame, once half way place all the boards on and see if you can get last board on without having to cut it down, this saves time and looks better.
10. Finally, you have enough trimmed down decking boards to cover both ends and one side. Fit ends first which are cut to correct length. Lastly do the front or longest side. You may have to join two lengths together, if so fit and then cut off with a saw.
11. Decking is now complete, enjoy!

If you are unsure or do not understand the instructions, please contact us either via email on info@layzeeliving.co.uk or via telephone on 02078673959.