ASSEMBLE Top Seat, Vertical and Cover 6 FRAME a) PRE-ASSEMBLING VERTICALS Put cover bracket as shown in the figure. Tighten up #12 Sheet Metal Screw. Put Resin Upper Joint as shown in the Figure, tighten up #12 Sheet Metal Screws. **Upper Joint** P.No.0341 12 Sheet Metal Screw <mmy) In case of using Steel Joint, Upper and Lower Joint are same b) INSTALLING VERTICALS Hook Assembled Resin Upper Joint over the top rail. Secure the bottm of vertical to Resin Lower Joint by #12 Sheet Meal Screws, 3/4 Continue installing verticals in this manner All around the pool. P.No.0341 #12 Sheet Metal Screw Lower Joint **<=mm**() Attention! Similar to Upper Joint. c) INSTALLING TOP SEATS Place each of the top seat over the upper joints and secure with #12 Sheet Metal Screws. Install all of top seat in this way around entire pool. Top seat are installed between verticals. Each end of top seat rest on upper joint and attached to it. It may be necessary to move the complete verticals slightly to left or right to accommodate the top seat. Do this carefully as not disturb the earth mound, Check all screws to be sure they are tight.

