

How to Replace Coloured Side Panels

(TIP: the following instructions apply with the BIBO facing you).

Overview

Parts/Tools Required

1. Replacement coloured side panels.
2. Phillips screwdriver (PH2), preferably a stubby or long version.
3. Plastic UV lamp key or small flat screwdriver.

Work Instructions

Removing top and side panels

1. **Switch off and unplug the BIBO from the mains electricity.**
2. Remove the top lid and drip tray and set aside.
3. Unlock and remove the UV lamp. *(Pic.1-2)*
4. Remove screws (8x) in the top panel then ease it off carefully from back to front. *(Pic.3-4)*
5. Remove top and bottom screws (2x) at the back of the left hand side panel. *(Pic.5)*
6. Remove screw (1x) securing front of left hand side panel located on the left of the drip tray cavity under white locking springs. *(TIP: take care not to strip the screw head). (Pic.6)*
7. Repeat the same process for the right hand side panel.
8. Remove each side panel by pulling out carefully from the bottom rear first and working your way forward. If necessary tap it gently with your hand along the top rim to dislodge it.

Refitting side and top panels

9. Refit panels in reverse order to steps 3-8 above, ie refit side panels followed by top panel.
10. Ensure all screws are tight.
11. Reinsert UV lamp.
12. Switch on the power supply and do a final check on the operation of the machine.

Images

