

INSTRUCTIONS

HOW TO MAKE YOUR BATHTUB OR SHOWER SLIP RESISTANT

EQUIPMENT NEEDED *(Photo 1):*

- One (1) can of SlipDoctors' Anti-Slip Spray for Fiberglass, Acrylic or Porcelain Bathtubs/Showers
- Masking Tape
- Painter's Paper

(Note: for porcelain bathtubs, please repair any chips prior to application. Repair kits can be purchased at your local home-improvement store.)

INSTRUCTIONS:

1. Clean the bathtub or shower, removing all soap, oils, hair and other contaminants.
2. Make sure the bathtub or shower is completely dry prior to application.
3. Open all windows and vents for proper ventilation.
4. Optional: Sand surface lightly to promote good adhesion. Remove all residue prior to application.

(Note: we do not recommend using black sandpaper, as it can leave behind small black dots that may be visible after using the clear spray.)

5. Tape off application area using masking tape. *(Photo 2)*
6. Use painter's paper to protect surrounding areas from overspray. *(Photo 3)*
7. Shake can for 2-3 minutes. Spray in a sweeping motion over area. Wipe up all overspray with a towel.
8. If a second coating is desired, apply 30 minutes after first application. (one coat is preferred)
9. Slowly remove all tape and paper shortly after application. If you pull too fast, it may remove the glaze from your porcelain bathtub.
10. **Allow 24 hours** before use to allow product to fully cure.
11. Enjoy your new slip-resistant bathtub or shower! *(Photo 4)*
12. If you like this product, send us your feedback by emailing cs@slipdoctors.com or by posting a review on Amazon.

QUESTIONS OR COMMENTS? WE WANT TO HEAR FROM YOU!

Email: cs@slipdoctors.com

Phone: 888-436-5404

Visit our website www.slipdoctors.com for additional products for your home and business.



Photo 1



Photo 2




Photo 3



Photo 4