

CLA-021-043 FIRST IMPRESSION CARACOLE CLASSIC

ASSEMBLY INSTRUCTIONS

PLEASE UNPACK ALL PARTS AND CHECK AGAINST PARTS LIST ON THIS INSTRUCTION SHEET BEFORE DISCARDING PACKING AND CARTON!!

- (1) Attache the "Z" Bracket to the wallboard with screws provided (A).**
- (2) Hang the mirror on the wall with "Z" Bracket .**

*** NOTE KEEP THIS SHEET!!! ***

In the unlikely event that you would need a replacement part for your furniture, please contact your local authorized Caracole International dealer. If you need replacement hardware quickly, it could be purchased from your local hardware store.

	CLA-021-043	
	FIRST IMPRESSION	
Part Description	Part No.	QTY
"Z" Bracket	CLA-021-043-30429	1

RTA Hardware		
	Hardware List	Q'ty
A	Screw(4.2X44MM)	4



