



Caution: Assemble the tip restraint hardware bag to the center of the upper edge of the back panel.

