



Installation for House Wrap Behind Brick or Aluminum/Vinyl Siding

Please read and follow all of the steps below to ensure proper installation.

Note: Upon receipt of your radiant barrier, store in a dry covered location; leaving the barrier exposed to the outdoor elements can cause the aluminum to corrode and potentially reduce its effectiveness at blocking the maximum amount of radiant heat possible.

Product Suggested:

- **RadiantGUARD® Ultima-FOIL** breathable (this version is perforated to allow moisture from home to easily pass through and out of your home).

Materials Needed:

- Tape Measure
- Scissors or Utility knife
- Staple gun and standard staples
- Large head nails or plastic washer head nails.

Instructions:

1. Prior to installing the exterior finish, staple the product (vertically or horizontally) directly to the exterior side of the structural panel.
2. Overlap the seams by 2".
3. Attach 1" x 2" furring strips over the radiant barrier to which to attach exterior wall. Furring strips are necessary to ensure at least a $\frac{3}{4}$ " air space as required for a radiant barrier to be effective.
4. Finish the exterior wall per manufacturer's installation instructions.

