



Installation for Masonry and Basement Walls

Please read and follow all of the steps below to ensure proper installation.

Products Suggested:

- **Reflex-AIR™ Double Reflective or White / Reflective Bubble** insulation

Materials Needed:

- Tape Measure
- Utility knife
- Scissors
- Staple gun and 5/16 staples
- 2 X 2 furring strips

Installation Instructions:

1. Check the area you are insulating and make any needed repairs before installation **Reflex-AIR™** insulation.
2. Use adhesive caulk or nails to attach furring strips to the wall 16" or 24" on-center. Use small pieces of tape to hold furring strips against the wall until the caulk has thoroughly cured.
3. Install bubble insulation to the middle of the 2 X 2 furring strip frame. Staples should be placed every 3" to 4". If using **WHITE** insulation, the white poly side should face the interior of the building.
4. Finish wall with interior panel per building code.

