

Rev.01 REF.: MCL002 ASSEMBLY INSTRUCTIONS KIT ROD FOR CLOSET STEP 01 SUPPORT FIXATION - DEPTH 14" FIX THE SUPPORTS ON THE SIDE PANELS (N2). 2 Ð AT DEPTHS OF 14 " FIX THE ROD TO THE . FRONT HOLES **STEP 02** • TUBE HANGER FIT . . . . . . Ð FIT THE TUBE ROD ON THE SUPPORTS FROM TOP TO BOTTOM