brume

glass safety stickers
fitting instructions

Please read the instructions before fitting your safety stickers.

Tools you will need:
A window scraper
Credit Card
Spray bottle containing detergent solution (3-4 drops of fairy liquid added to 500ml water)
Spirit Level & Masking Tape

1. Wash your window and make sure the glass is free of grit and fluff. Remove any surface debris with the window scraper.

2. With a spirit level mark with masking tape where you'd like the safety stickers to be positioned. It is best to have a line of stickers at the average standing eye level (The recommended positions are at 90cm and 150 cm from the floor).

3. The stickers are pre-spaced and around them there is a positioning frame made from the same material. This will help guide the location of your sticker and will be removed after installation. As the sticker strip is quite long you may wish to cut it into two sections for easier application.

4. Take your sticker strip and lay it out on a hard surface with the stiff white backing face up. Give the backing a firm rub down with a smooth edged credit card.

5. Then carefully remove the stiff white backing. The stickers should remain intact on the soft sticky application tape. If the sticker does not stay on the tape rub over the stiff backing again and try again.

6. Spray the sticky surface of the sticker with the detergent solution. (Try not to drench the application tape – the solution should be aimed at the sticker only).

7. Position the application tape and sticker on the window with a piece of masking tape in each top corner. Starting at the top, rub over the soft sticky application tape with the credit card with firm strokes and smooth the sticker to the window. Start at the top and work down and out to each edge.

8. Wait until dry (this may take 1-4 hours). Then starting at the top carefully peel away the soft application tape. If the sticker lifts off with the application tape simply rub it back down again and try again. Finally remove the positioning frame.