

brume

bubble glass stickers

fitting Instructions

Please read the instructions before fitting

Tools you will need

A window scraper

Credit Card

Spray bottle containing detergent solution (3-4 drops of fairy liquid added to 500ml water)

1. Clean your window and make sure the glass is free of grit and fluff. Remove any surface debris with the window scraper
2. Spray the glass with a generous mist of the detergent solution.
3. Wet your fingertips with the detergent solution and then carefully peel off a sticker from the backing. Spray the sticky side with the detergent solution
4. Position each sticker in the desired location
5. Gently smooth over the sticker with the credit card to remove any bubbles and solution. The sticker should be thoroughly fixed within 24 hours.