



Attention

Align the arrows on the base and the connecting shaft, then fix the connecting shaft onto the base.

