




## <u>Instructions for Using a Task Force Tips DECON/pak</u>

- Unscrew black circular cap on front of unit
  - Add 6 litres of water
  - o Add 2 litres of AJ Stone (P/N# GDGS-FO) Agent
- Fluid level should be just below the circular fill port's bottom edge
- Turn the flow rate governor so that the red knob is located in the middle of the word "DECONTAMINATION" and is therefore flowing at 0.25% for optimal performance.
- Connect a 38mm or 45mm water line to the swivel from a water source.
- Twist the central handle to activate or deactivate flow.







AJ Stone GDGS-FO Agent