

PAD EYE ANCHORS

BE CAREFUL! You only get one shot. Once 3M VHB (very high bond) adhesive makes contact, it cannot be removed without ruining the mounting tape. Make sure you know what you're doing before removing the backing.



MEASURE SPACING

Clip MoonShade into Pad Eyes and use canopy as a guide to measure the spacing between anchor points. Mark mounting location.



MOUNT ONE PAD EYE

Clean the mounting surface well. Remove the 3M VHB cover from one anchor. Mount first Pad Eye by pressing adhesive firmly into place.



CHECK SPACING

Double check the placement of the second Pad Eye using the MoonShade canopy as a guide. Repeat former step with the second Pad Eye.



FASTEN HARDWARE

Once both anchors are stuck in place, fasten with screws. We suggest using a sealant such as butyl tape or lap sealant to help prevent leaks.