

Zadro™



Made In America

# Z'Fogless™ Water Mirror

## GUARANTEED FOG FREE

### 3 Easy Steps

**1**



Slide mirror portion straight up from base

**2**



water reservoir

Hold the mirror portion with water reservoir and fill with warm water from your shower

**3**



Slide mirror portion back down onto base



Your patented Z'Fogless Mirror is ready for use



**Made in the USA**

**Fog-Free**

**4 LEDs Illuminate Your Face**

**On/Off Touch Sensor**

**Flexible Razor & Accessory Holder**

**Included Storable Squeegee Wipes Away Shower Overspray**

### 2 Mounting Options

Select a mounting area in your shower free of overspray and at eye level. Clean the surface before mounting by rinsing and letting dry, then wiping with rubbing alcohol.



**1**

**Suction Cups:** Insert suction cups (X3) into the keyholes on the base. Only install on smooth surfaces such as glass or smooth tile. Moistening the inside of the cups will improve adhesion.

\*Will not hold on porous surfaces.



**2**

**Tape:** Ensure the surface is cleaned with alcohol and allowed to air dry. Press the tape firmly to the mirror base and then to the wall.

After the mirror base is firmly attached, slide the mirror reservoir onto the base. Regularly check to ensure the mirror is firmly secured.



Zadro Products, Inc.  
*Innovative Ideas That Make Life Easier™*  
 Huntington Beach, CA  
 Phone: (714) 892-9200  
 Fax: (714) 892-7477  
 E-mail: ZadroInc@ZadroInc.com  
 Website: www.ZadroInc.com

For more information visit us online at www.ZadroInc.com

Requires (3) AA Batteries (Not Included)  
 Qty: 1  
 Dimensions: 6"L x 4"W x 11"H  
 Designed and Manufactured in the USA Exclusively by  
 © Zadro Products, Inc.  
 Patent #: 8,476,901, D695027



Rev.07172015