

F354-C

4

5

2

5

Parts Diagram

2017 - 2024 Ford F250 - F350 With 6.2L, 6.8L, 7.3L Engine *Max : 176 - Inch Maximum Wheelbase*

10.0


3

.e0 | ||

9

E

1



Customer Support

And

Warranty information





Thank you for purchasing a MPI Exhaust Technologies System and letting MPI Exhaust customize your ride today! We have a friendly and knowledge staff so contact us with any questions. Enjoy the Sound of Perfection

Questions -

ONLY contact MPI Exhaust Technologies if any products are possibly missing, damaged, during shipping or if you have any question about the products. Call @ 406-669-3286

Installation -

Watch the tutorial YouTube videos before installation or calling @mpi exhaust, we have a very knowledgeable staff that has installed hundreds of these kits.

Warranty -






- 1. Remove Factory System Cut Infront of dual in single out resonator as close to the case welds as possible on the inlet side
- 2. Slide Pulse chamber over Factory pipe then Clamp Pulse Chamber, ensure offset away from driveshaft and leveling for Best fitment
- 3. Install the Right side Head Pipe, then trim to Wheelbase (view diagram) Snug Clamps as you go, don't final tighten yet
- 4. Install muffler assembly Ensure Rear Muffler Measurement is correct to ensure proper tailpipe placement with Offset Toward Front
- 5. Install Head Pipe Hanger—Final tighten all clamp to this Point
- 6. Install Rear Hanger Behind Mufflers
- 7. When Bullnoze are installed ensure proper rear end clearance

Side View

8. Clean finger prints off tips with glass cleaner, clean pipes with brake clean,

* ensure turn downs are below reared end to prevent excess heat on rear end housing



F354-C

Instruction

F354 - C Instruction Packet

2017 - 2024 Ford F250 - F350 With 6.2L, 6.8L, 7.3L Engine *Max : 176 - Inch Maximum Wheelbase*





F3-4