



Align the bracket so it runs parallel to the frame tubes.  
It is much easier to mount the bracket if the exhaust pipe is removed

## 308 Mounting Instructions