



Align the bracket so it runs parallel to the frame tubes.
It is much easier to mount the bracket if the exhaust pipe is removed

308 & 326 Mounting Instructions