

## **Mounting RZR 1000 XP**

### **Rock Sliders In Conjunction with Factory Skidplate**

**P/n's 775FB, 786FB**

If you're wanting to install our rock sliders on your RZR 1000, but are still running the factory plastic skidplate, you will need to do some minor trimming on the factory skidplate.

Where you need to trim, is where the skidplate comes over and is attached to the rear suspension arm pivot. Remove the screws and just trim off the part of the plate that is on top of that pivot mount.

You will now need to re-secure the body skidplate in another location. You can do this in any location you would like that will re-secure the skidplate to your liking. What we do when we install these, is re-use the screws you removed from the factory plates, these are a self-tapping screws. After finding suitable locations use a 13/64" or #7 drill and drill through the plate and into frame and install the screws.