

Ricochet RZR 1000/900 installation instructions

Foot well skids Part# 775L

Step One: It is easiest to install these with the front wheels removed, also if you have aftermarket skid plates you may need to remove those in order to be able to drill for the bottom mounts.

Step Two: With the machine safely off the ground and the front wheels removed place the contoured plate into position. There are different plates for the left and right side. With the plate into position drill a 1/4" hole through the plastic. Keep the plate in position and drill all three holes using the plate as a guide.

Step Three: You can now start your hardware for the holes you just drilled. The small washer will go against the aluminum plate, and the large fender washer will go on the inside of the cab against the plastic. It may take two people to start and tighten the hardware.

Step Four: Tighten all three bolts that you have started.

Step Five: The flat rectangle plate goes next to the plate you just installed. Get that plate into position and drill your first hole.

Step Six: With the plate in position start the hardware, and drill your second hole.

Step Seven: Tighten both of the bolts for the flat plate.

Step Eight: Repeat steps One through Seven for the other side.

If you have any questions or problems we have a video on our you tube channel showing the installation process, and of course you can always contact us through email or telephone.

Hardware list for 775L

- 10) 6x20 hex bolts
- 10) M6 washers
- 10) 1/4x1 fender washers
- 10) M6 nylock nuts