



4) M8X45 TORX

997-3

2) M8X35 TORX
2) 832-8 Cup Washers

TOYOTA TACOMA TRANSMISSION SKID PLATE INSTRUCTIONS.

You will need a T40 socket drive for the bolts provided.

Begin by removing the back two bolts on the stock front skid plate.

Remove the four stock bolts on the cat tube connections.

Loosen, but do not remove the two bolts on either side of the cat tube connection on the outer frame.

Take the two 8x35 bolts (shorter) and place the cupped washers on these bolts, you can then install the front of the skid plate over the stock skid plate using these bolts. Leave these loose now so you can adjust for the best fit.

Take the four 8x45 bolts (longer) and install all the back connections. Once all the bolts are started you can adjust the plate accordingly and tighten down all six locations.

Once the skid plate is installed don't forget to tighten down the two bolts on either side of the frame cat tube connections.

One of our customers has made a Youtube video of installing this skid plate, scan the QR code below to watch the video.

