

### Installation Tips For Motorcycle Skid Plates

1. Remove any factory skid plates, crash bars, and case guards.
2. Some of the plates use clamps of different sizes. If you received a clamps location chart, place the different clamps in the location indicated. In some cases you will need to hang the clamp on the frame before mounting the skid plate.
3. We recommend using a little bit of blue Loctite on each bolt to keep them secure.
4. Install all of the clamps loosely, then adjust the plate for the best fit. Once you have all of the clamps started you can tighten them all down. You will need a T40 Torx drive for the 8mm buttonhead and a T30 socket drive for the 6mm buttonhead. If any hex bolts have been included, you will need a 13mm or 10mm socket head.