



INSTRUCTIONS *Residential*

Questions or concerns? We are glad to help. Contact info below.

If you are satisfied with your purchase, please leave us a review. Your feedback is important to us and our customers.

Kit Includes: Spray Bottle, Solution, Towel, Squeegee, Soft Measuring Tape, Cutting Stick, Cutting Knife

Before Application: Fill spray bottle with filtered water almost to the top. Add solution and shake to mix. Trim off 1 inch of each side of the film on a flat surface before applying.



01 Use premixed solution to clean the window. Then use the provided squeegee to remove any dirt/debris that could be on the window.



02 Spray the film & window. Apply either side of the film to the window. Then spray again. Squeegeeing from center to edge, remove as much solution out from under the film as possible.



03 Using the cutting stick along with the knife. Carefully trim off any excess film.



04 To finish, spray again then wrap the squeegee with napkin and begin squeegeeing from the center to the edge. Apply firm pressure to ensure sure all bubbles are removed from under the film and that all edges are flat.