



## INSTALLATION INSTRUCTIONS

**PART No.** 30006-30015

**MODEL No.**

**Interior Door Handle Bezel**



**Clean the surface of the interior panel with alcohol.**

Place the Stainless interior bezel over the door handle with the wide side at the top.

Peel the red backing from the 3M tape then place the door handle bezel in position.

Press firmly on the bezel to ensure that the tape has made contact against the door panel.

Note: The 3M Tape works best in temperatures of 50-100 deg F.



## INSTALLATION INSTRUCTIONS

**PART No.** 30006-30015

**MODEL No.**

**Interior Door Handle Bezel**



**Clean the surface of the interior panel with alcohol.**

Place the Stainless interior bezel over the door handle with the wide side at the top.

Peel the red backing from the 3M tape then place the door handle bezel in position.

Press firmly on the bezel to ensure that the tape has made contact against the door panel.

Note: The 3M Tape works best in temperatures of 50-100 deg F.