



## INSTALLATION INSTRUCTIONS

**PART No.** 30404-30435

**MODEL No.**

Align the bottom edge of the guard with the body tub. Mark the two mounting holes with a permeant marker. Center punch the mark, then drill a pilot hole with an 1/8" drill bit. Re-drill the holes using an 11/32" drill bit. Bolt the corner guards in place using the stainless-steel bolts provided.

### TOOLS REQUIRED

Drill

1/8" And 11/32" Drill bits

1/2" Wrench or 1/2" Socket and ratchet

Hammer and center punch



## INSTALLATION INSTRUCTIONS

**PART No.** 30404-30435

**MODEL No.**

Align the bottom edge of the guard with the body tub. Mark the two mounting holes with a permeant marker. Center punch the mark, then drill a pilot hole with an 1/8" drill bit. Re-drill the holes using an 11/32" drill bit. Bolt the corner guards in place using the stainless-steel bolts provided.

### TOOLS REQUIRED

Drill

1/8" And 11/32" Drill bits

1/2" Wrench or 1/2" Socket and ratchet

Hammer and center punch

