



INSTALLATION INSTRUCTIONS

PART No. 30517 , 50517

MODEL No.

Strut Rod Kit



Remove the existing strut rods.
Place the New Stainless Steel Strut Rods in place making sure that the passenger side is positioned on the passenger side. The “L” shaped piece is the bracket for the Prop Rod.
Fasten using the stainless steel nuts and bolts provided.



INSTALLATION INSTRUCTIONS

PART No. 30517, 50517

MODEL No.

Strut Rod Kit



Remove the existing strut rods.
Place the New Stainless Steel Strut Rods in place making sure that the passenger side is positioned on the passenger side. The “L” shaped piece is the bracket for the Prop Rod.
Fasten using the stainless steel nuts and bolts provided.