



INSTALLATION INSTRUCTIONS

PART No. 30711, 30712, 30713
**Anti-Theft Door Nuts for
1997 to 2017 TJ and JK Wrangler**



REQUIRED TOOLS

T50 TORX (JK)
13mm SOCKET (TJ)

KIT CONTAINS

ANTI-THEFT DOOR NUTS
ALLEN WRENCH

QTY

4 (30711, 30713) / 8 (30712)
1

1) Remove Your OEM Door Nuts

Using a T50 TORX (2007-2017 JK) or a 13mm Socket (1997-2006 TJ), remove your OEM door nuts from each door.



2) Install Kentrol Anti-Theft Door Nuts

Using the included allen wrench, install the Kentrol Anti-Theft Door Nuts.



3) You're Done!