



## **INSTALLATION INSTRUCTIONS**

**PART No.** 30572, 40572, 50572, 80572

**MODEL No.**

### **Hood Hinge**

#### **Tools Required:**

Torx T-27 Screwdriver, 13mm Socket or Wrench, Flat screwdriver, and T-40 Torx socket.

Remove the cowl vent plate by removing the four screws two from each end of the cowl plate, pry up the four center plastic pop-in inserts and pull straight up and out. Remove the plastic cap of the wiper arms by pulling out the sides of the cover and pivot back. Remove the hex nut holding the wiper arms then remove the wiper. The cowl plate is now free to remove. Remove the two hex bolts holding the hood hinge to the body using a 13mm wrench or socket. Do one side at a time. Remove the two star point bolts of the hood hinge with a T-40 socket. The hood hinge is painted with the hood we recommend that you cut around the hood hinge using a razor knife, so you will not chip the paint when removing the hood hinge. Place your new Stainless Steel hood hinge in place and using the stainless bolts supplied. Fasten the hinge to the hood and the steel bracket of the body. Repeat this process for the other hood hinge. Re-install the cowl plate then the wiper arms.

**We recommend that you coat the threads of the stainless steel bolts with anti-sieze compound when installing them.**

