



INSTALLATION INSTRUCTIONS

PART No.

80709

Jeep® CJ, YJ, TJ Wrangler
Heritage Taillight Covers



REQUIRED TOOLS

Phillips Screwdriver

KIT CONTAINS

Taillight Cover
No. 8 Screw
Spacer

QTY

2
8
8

1) REMOVE FACTORY HARDWARE

Using the screwdriver, remove all four (4) screws on the taillight.



3) REPEAT STEPS 1 AND 2 FOR OPPOSITE SIDE

4) ENJOY YOUR NEW TAILLIGHT COVERS!

2) MOUNT YOUR NEW TAILLIGHT COVERS

Using the supplied screws and spacers, install your new taillight cover. **DO NOT OVERTIGHTEN.** Ensure the spacer goes between your OEM taillight and the new taillight cover.

8070900