



# INSTALLATION INSTRUCTIONS

**PART No. KEN30722 & KEN50722**

Jeep® JK Wrangler  
CB Antenna Mount



## REQUIRED TOOLS

13mm Socket or Wrench  
Ratchet

## KIT CONTAINS

CB Antenna Mount  
M8 x 1.25 x 40mm SS Hex Bolt  
M8 SS Washer  
M8 SS Lock Washer

## QTY

1  
2  
2  
2

KEN30722 & KEN5072200



## **INSTALLATION INSTRUCTIONS**

**PART No. KEN30722 & KEN50722**

**Jeep® JK Wrangler  
CB Antenna Mount**

### **1) INSTALL**

Whether you have an aftermarket backside or factory tire carrier, with a 13mm socket or wrench. Remove the 2 top right bolts, and put them away for future use.

With the mount in hand turn and place the two beveled bolt holes up to the tailgate holes. Using the included hardware and a 13mm socket or wrench, secure the mount into your tailgate. Be sure to not over tighten as it may damage your body.

### **2) CB ANTENNA INSTALL**

Install your CB antenna into the mount according to the manufacturer's instructions.

**ENJOY YOUR NEW KENTROL CB ANTENNA MOUNT!!!**