

How to Install the Protect-O-Pad

WARNING: Do not mount magnetic car toppers onto sun roofs, fiberglass vehicles or non-ferrous metal vehicles such aluminum or stainless steel!

1 Clean surface area before applying Protecto-pad



2 Peel the **Protect-O-Pad** from the backing and place onto vehicle



3 When the pad has been installed, wipe down area and use a credit card or squeegee to remove any bubbles.



4 If you have any questions, call us at **1-800-321-1850** and we'll be happy to help