

Little Bale Feeder Assembly Instructions

Thank you for purchasing the NZ Made
Kiwi Bale Feeders - Little Bale Feeder.

PARTS LIST

Please check you have all the required parts:

- 2 x end frames
- 2 x centre frames
- 8 x M10x65 bolts
- 10 x M10x40 bolts
- 6 x M10 washers
- 18 x M10 nyloc nuts

TOOLS

16mm and 17mm ring spanner or equivalent.

BALE FEEDER ASSEMBLY

• Take one end frame and one centre frame and connect the two using two M10x65 bolts. Make sure the steel mesh is on the outside of the frames. So these bolts up finger tight for now, until all the parts are bolted together.



• Bolt the other end frame to the centre frame with two M10x65 bolts.



• Bolt the last centre frame to the end frame with two M10x65 bolts at each end.



• Bolt each skid to the end frames using four M10x40 bolts. There are two height options for the skids.



• Place the lid on to the bale feeder, bolt it to the frame with two M10x40 bolts with three washers between the lid and the frame on each side.



Tighten these bolts fully, then back them off 1 turn.

Your Little Bale Feeder is now ready to use!