

RUSTPROOF CLEAR™

Specification Sheet

Application Area	Number of Coates	Coating Thickness
Underbody / Inside of doors / Floor of Vehicle	Apply 3 heavy coats with aerosol, by brush or spray gun. Allow 30 minutes between coats.	A minimum dry film thickness of 75 microns must be achieved.
External Plastics / Bumpers	Apply 3 coats with aerosol, by brush or spray gun. Allow 30 minutes between coats.	A minimum dry film thickness of 55 microns must be achieved.

Before using spray gun, run general purpose thinners or acetone through the lines. Repeat the process after treatment to clean the lines and spray gun.

PLEASE NOTE: Before applying Rustproof Clear product on pre-rusted surfaces, always clean the surface by wiping down with general purpose thinners to remove grease, dirt, oils and impurities leaving a clean dry surface.

If rust is present, it should be removed before applying Rustproof Clear. For best results use a wire brush to remove rust flakes. Then apply Action Gel to remove remaining rust and restore the metal surface. Finally wipe down with general purpose thinners before applying the Rustproof Clear.

Before the use of Rustproof Clear, a test should be undertaken on an inconspicuous area to ensure the desired result.

DO NOT SPRAY THE OUTSIDE/PAINTED BODY OF A VEHICLE.