



Polaris Xpedition Instruction Sheet

Thank you for your purchase. We are working on editing a video to post on YouTube for this model, but have had so many people inquiring about it that we wanted to get it released as soon as possible.

After unpacking your box, the first thing you want to do is lay your carpet out on a flat surface overnight to help remove any fold marks before installing. Carefully peel up and separate each piece of hook & loop. (When we adhere this to the carpet it is stuck on so well that it overpowers the adhesive when you go to install it.) Line up your carpet in the designated location and peel the tape off one by one, holding the carpet in place.

2 & 5 Seat, Front Driver side:



2 & 5 Seat, Front Passenger side:



2 & 5 Seat, Under Front Seats:



2 & 5 Seat, Side Column: Cut on marked lines for 5 seater



5 Seater only: Rear Driver side:



5 Seater only: Rear Passenger side:



Back Wall: Remove the “loop” side of the hook & loop and discard. The hook is strong enough to hold the factory Polaris mat on the back wall. If you have issues reinstalling your bolts through the back wall don't use the big washers that were on them.

5 Seater



2 Seater

