



HOW TO COAT A FLOOR WITH SIMIX CERAMIC FLOOR COATING

Tools & Supplies Needed

- Simix Ceramic Floor Coating or Simix High Shine Ceramic Floor Coating
- Simix Kitchen Degreaser
- Water
- Mop and bucket
- Clean dust mop
- Fan
- Burnisher
- Auto scrubber
- red pads
- 800 grit diamond pads
- 3000 grit diamond pads

FLOORS HAVE TO BE COMPLETELY PRE-STRIPPED AND STRIPPED USING THE SIMIX METHOD BEFORE APPLYING COATING. NO EXCEPTIONS.

APPLY THE COATING

1. Clean flat applicator mop. Do not assume a new mop is "clean." New mops are treated with chemicals. These chemicals must be washed off in a clean mop bucket with hot water and a small scoop of Simix Kitchen Degreaser.
2. Shake bottle of Simix Ceramic Floor Coating or Simix High Shine Ceramic Floor Coating.
3. FOR HIGH SHINE COATING: Mix 4 parts water to 1 part coating in a backpack pump-up sprayer. This means if you are using one gallon of Simix, you need four gallons of water.
4. FOR REGULAR CERAMIC COATING: Mix 2 parts water to 1 part Simix Ceramic Floor Coating in a backpack pump-up sprayer. This means if you are using one gallon of Simix, you need two gallons of water.

5. If you are doing an aisle, spray two lines of coating about a foot away from each shelf.
6. Second person spreads coating using microfiber mop and side-to-side motion.
7. Allow floors to visibly dry (at least 20 minutes) before applying next coat. If floors are still wet after ten minutes, you can use a fan to help dry faster if needed.
8. While coat is drying, rinse microfiber mop heads in warm, clean water. Wring them dry.
9. Apply three more coats using the same method.

POLISH

1. Wait 20 minutes after last coat.
2. Polish with 800 diamond pad.
3. Dust mop.
4. Polish with 3000 grit diamond pad.

IF YOU ARE WAITING TWO HOURS, HERE'S HOW TO APPLY FOUR MORE COATS

1. Apply four more coats using the same method.

IF YOU ARE COMING BACK THE NEXT DAY, HERE'S HOW TO APPLY FOUR MORE COATS.

1. Autoscrub using 800 pad and one large scoop of Simix Kitchen Degreaser.
2. Detail mop and allow the surface to dry.
3. Rinse with red pad with one small scoop of Simix Kitchen Degreaser per gallon of water.
4. Apply four more coats using the same method you used the day before.
5. Burnish with 3000 grit diamond pad on your burnishing machine.