

## INSTALL INSTRUCTIONS

### C-VS-0909-CHGR-PM-1 and C-VS-0909-CHGR-PM-2 2021-2023 Dodge Charger PPV Vehicle Specific Console


#### 18" inches of Equipment mounting space with mount for Pocket Jet Printer

#### TOOLS REQUIRED:

Phillips Screw Driver                      Standard Socket set                      T-20 Torx Bit                      Metric Socket set

#### INSTALLATION PARTS AND MOUNTING HARDWARE:

<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART#</u>
1	Driver side trim panel	12592
1	Passenger side trim panel	12887
1	Front printer trim panel	12593
1	Printer paper roll rod	12569
2	7/8" PLUG	13401
4	1/4 Flat washer	16122
4	1/4-20 X 1 1/4 Hex bolt	16328
2	1/4" x 3/4" Lag screw with washer	16359
8	#8-18 x 1/4" Flat head screw	16425
1	USB-A to 90° USB Mini-B extension cable	16934 for PocketJet 6 and 7 (C-VS-0909-CHGR-PM-1)
<b>OR</b>		
1	USB-A to 90° USB-C extension cable (DS-DA-340)	37554 for PocketJet 8 (C-VS-0909-CHGR-PM-2)



#### Always!

- Read all instructions before installing any Havis, Inc. products.
- Use hardware provided with install kit



Remove forward O.E.M console plastic cover and remove two (2) nuts from front floor bracket. Nuts to be reused later. (10mm)



Remove bolts that hold underside of extrusion to rear floor bracket. (7/16 wrench) Remove rear floor bracket bolts and center console bolt. (10mm)



Remove O.E.M. plastic center console



Remove OEM lighter plugs and AUX panel from factory center console. Plug O.E.M. wire harness back onto original connectors.



Attach the front printer trim panel (12593) using four (4) #8-18 x 1/4" flat head screws. (16425)




With the front printer trim panel installed, place the console tight to the dash. It is easiest to pick up the rear of the console and slide it towards the dash and then lower the rear.



Install OEM AUX panel and 12V outlets into the side of the console. Plug into factory harnesses.



Make sure the ignition key sense module is moved out of the way and line up the U bracket to the OEM studs.



Place the ignition key sense module on the OEM studs and reinstall with previously removed nuts.



Use 1/4 x 3/4 self-threading screws (included in hardware kit) to loosely attach rear of console to existing floor inserts. Inserts located under rubber mat as shown. (7/16 socket)



Attach driver side trim panel on with # 8 x 1/4 Flat head screws.  
(included with hardware kit)



Attach passenger side trim panel on with # 8 x 1/4 Flat head screws.  
(included with hardware kit)



Pull USB and power cable connections through openings at the left of the printer mount bracket. Plug them into their respective locations and install printer into the mount.



Install plastic rod (12660) through the paper spool and place into the console. Feed paper into the printer.



Close lid and confirm final operation and fit. Install control heads and accessories.



To open the printer lid, rotate the motion device out of the way.



View of DS-PAN-702, C-MD-312, KBM-201, KB-101, C-AP-0325, and C-CUP2-I



Installation is now complete