

# How To Install Peel & Stick Wallpaper

## Step 1. Check your Peel & Stick Wallpaper

- Check all batch & pattern numbers match
- Check all rolls are undamaged
- Check all panels match roll to roll & edge to edge
- Check you have sufficient rolls to complete the job, allowing for design repeat

## Gather your tools

- Tape Measure
- Level (or Plumb Bob) & Pencil
- Ruler or Straight Edge
- Utility Knife & Plastic Smoother
- Step Stool or Step Ladder



## Step 2. Prepare your walls

**1. Let the product acclimate in the room it will be applied,** for a minimum of 2 hours.

**2. Clean surface.** Use a clean Alcohol saturated cloth to remove any dust from your wall surface. You may need a damp cloth or cleaners to remove excessive dirt and dust followed by the alcohol wipe. If so, allow an additional 24 hours to dry. Do not apply product to moist walls! Our wallpapers adhere to smooth surfaces only, smooth out any bumps and fill any cracks in the wall.

**3. If the wall has been freshly painted, allow it to fully cure for at least 3 weeks** prior to installing your wallpaper. Consult with the paint manufacturer for proper cure times.

**4. Test product in an inconspicuous location** of surface before applying to desired location. You have a small piece of wallpaper added to your order.

Surfaces must be smooth, dry, clean & firm. The product may not adhere to unclean/textured surfaces.

## Step 3. Hang your first panel

**1. Invite a friend...** hanging wallpaper is a two-person job so you could use a hand and share the fun.

**2. Apply wallpaper from left to right.** Start in the top corner of the room or wall.

**3. Peel about 12 inches (30cm) of the backing away.** Apply the first panel to the top of the wall, allowing a bit of excess to overlap the ceiling. Working from top to bottom, pull the backing away carefully as you evenly press the paper to the wall.

**4. Remove the panel to reposition if needed.** Coloritto wallpaper adhesive is repositionable and removable.

**5. Use a plastic smoother to push out any air bubbles from the center outwards.** Applying moderate pressure use the smoother over the full surface area of the product to ensure firm adhesion to the wall. Do not stretch the material.

## Step 4. Apply remaining panels

**1. Apply the next panel according to the instructions above,** slightly overlapping & matching the pattern to the first panel. You can use paint tape to hold panels correctly.

**2. Slightly overlapping panels** by approximately 3/4" is recommended. If the product is not slightly overlapped when it shrinks back, it will leave a gap.

**3. Final stage.** Once you've applied all rolls, use a sharp utility knife to trim any excess at the edges of the wall and any excess paper on the right edge of your installation area.

**Now sit back, relax and enjoy your piece of art! You did it!**



### TIPS

If you are hanging this product around sockets or switches, switch off main power, unscrew fixtures & clean out all dust prior to starting.

To remove or reposition your wallpaper. Starting in a corner, carefully pry up the material from the wall. Peel at a slow speed, keeping the angle 90° and diagonal to the panel.

**We do not recommend** hanging Wallpaper on the following surfaces:

Textured Walls, Wallpaper, Brick/Cinderblock, Unpainted Drywall/Sheetrock or Plaster, Outdoors, Non-stick Paint.

Please **contact us** if you have any questions about wallpaper installation or any other questions.



**FAQ**

[www.coloritto.co](http://www.coloritto.co)

**EMAIL**

[colorittoshop@gmail.com](mailto:colorittoshop@gmail.com)

