

# How to Install



## PEEL & STICK DECALS

### BEFORE YOU GET STARTED

**You'll need to have:** masking tape, a level and a squeegee (or an old credit card).

*For freshly painted walls please wait 3-4 weeks before applying your decals to allow the new paint to cure.*

*Decals work best on eggshell, matte, semi gloss or satin finish paints.*

*We do not recommend installing on highly textured surfaces such as stucco, concrete or drywall primer finishes.*

### STEP 1 - LET'S GET READY

- **Choose the perfect spot.**
- **Clean the surface** with a damp cloth to remove any dust or grease which may cause the vinyl not to adhere properly.

### STEP 2 - LET'S GET CREATIVE

- **Mark out your pattern** on the wall with little pieces of masking tape. Decals are one time use so plan out your design carefully.
- **Take a step back** and look at it your pattern to make sure it is spaced how you like it.
- **Freestyle it:** you don't have to make a pattern!  
You can create a scattered look and not follow a specific pattern.

### STEP 3 - LET'S GET STICKING

- **Carefully peel each decal** off and stick onto the wall where you've marked with the masking tape.
- **Smooth down the decal** with your squeegee.

### STEP 4 - THE BIG REVEAL

- **Continue to create your pattern across the wall.**
- **Admire your amazing new decals!**