



ASSEMBLING CENTER MOUNT OVERHEAD UPRIGHT BRACKET.

With the bench top down on the floor, find the exact center of the bench top and center the bracket as shown. Make sure the bracket is flush with the back of the bench top, then mark four holes to be drilled. Using a 9/32" drill bit, drill the pilot holes about 3/4" deep being very careful not to drill through the wood top. Place the bracket back on the top making sure that it is flush with the back of the bench top and secure using 4-3/8" tap bolts and 4 washers.