

est. 1931



OVERHEAD STRUCTURE ASSEMBLY

MOUNTING SORTER UNIT TO UPRIGHTS



HARDWARE REQUIRED:



4 tap bolts 3/4" long



4 washers



4 rectangular nuts

MOUNTING A SORTER UNIT TO OCS

Note: This assembly will require two people. Begin with the sorter unit placed with the compartments facing forward. Place all 4 tap bolts with washer through mounting holes on sorter unit and loosely thread rectangular nuts to tap bolts. For straight overhead uprights, have two people lift the sorter unit above the top of the uprights and guide the rectangular nuts into the channel and slide the unit into desired position and tighten. If you have a 90 degree or angled uprights, you will have to tilt the rectangular nuts and bolt assembly, while keeping the nut parallel to the uprights, slide one side of the nut into the channel and the other side will follow... then tighten.