



Assembly Instructions

Mobile Bin Unit

Assembly of a Mobile Bin Unit.

*Note: These instructions may include bins or boxes you have not purchased. Begin by placing MBU base on a level surface. Lock caster brakes on swivel casters. Bolt uprights in place (returns on uprights should be facing towards the center) on both ends using four bolts and washers per upright. Each MBU should typically have five or six rows of bins (this may change depending on your particular configuration). The bin rails for the larger bins should be installed first, so that the larger bins will be on the bottom of the unit. The bin rails for the #2 bins will be configured so that they can hold five bins per side, the rails for the #1 bins will hold seven per side and the rails for the #0 bins will hold nine per side. After selecting the rails for the largest bin you have purchased, carefully insert it into the channel of the MBU upright on both sides with the tab inside the rail to the top. Slide rails down into position. *Note: It may be necessary to move rails down by tapping on alternate sides with a rubber or cloth covered hammer or other such object.* Insert remaining rails in the MBU continuing to put rails for larger bins in followed by rails for smaller bins. Attach handle by squeezing the ends towards each other and placing the ends of the handle into the holes provided on one side of the base.*

