

Ihome Adore

ASSEMBLY INSTRUCTIONS

STYLE#:: PWT230307-1

Parts:

- 1 PC Base
- 2 PC Screws
- 1 PC Screwdriver
- 1 PC Tempered Glass w/square pallet

1. Carefully unpack carton and place all parts on soft, smooth surface. Inventory all parts.
2. Remove the 2 screws from back of the square pallet with screwdriver.
3. Align the square pallet of tempered glass onto square base, carefully tighten 2 screws with screwdriver.

9667 Owensmouth Ave suite 100 | Chatsworth, CA | 91311

