



# Gladiator Tailgate Net

## *Installation Guide*

### **Tips:**

Every truck bed is slightly different. Spend some time finding your ideal mounting points and install with the help of a friend.

### **Required Tools:**

Drill with 1/16" bit (for pilot holes)

5/16" socket wrench or impact driver

**Recommended:** Rust prevention paste/solution

### **Steps:**

1. Hold the net up to the bed of the truck and find your ideal mounting location. Make sure not to drill through any post holes, taillights, or electrical components.
2. Mark where you are going to drill the pilot holes. This can easily be done by marking the holes through the footman loop (mounting bracket).
3. Once marked, remove the footman loop and carefully drill the pilot holes. Use two hands on the drill to keep it steady and prevent the bit from slipping out of place. Apply anti-rust paste to holes.
4. Mount/attach the footman loop brackets using the included self-driving screws. **DO NOT OVERTIGHTEN.**
5. Install the Gladiator Tailgate Net: Feed the straps through the footman loop bracket and double back into the hardware. Once all four straps have been fed through the hardware pull them all tight. The four straps should have even spacing on each side. The net should be taut enough that you can pluck the net at the top and bottom.

For any questions we are always happy to help. Please email us at [sales@gladiatorcargo.com](mailto:sales@gladiatorcargo.com) (with pictures if possible) or call our office at (888)386-4271.



