

1. If you are replacing OEM cab roof lights with these RECON RGB cab lights then you will simply mount the lights into the existing holes and use the OEM hardware
2. Connect the supplied wire harness to your OEM cab roof light harness by splicing the supplied red wire to power and the supplied green wire to the ground wire.
3. If you are installing these on a truck that did not come with OEM cab roof lights, then please locate the install guide for the corresponding make and model's cab lights which will give you the measurements for the cab lights.
4. After you mount the lights, you will need to connect the red RECON wire to a positive running light wire and ground the green RECON wire.
5. Once installed, scan the QR code on the wire harness(or below) and download the app which will enable you to control the multiple colors and functions of your new RECON RGB cab roof lights.



THANK YOU FOR PURCHASING FROM
GORECON.COM
AND ENJOY YOUR NEW CAB ROOF LIGHTS!