



Operation

Once assembled you can “plumb” your shower in two ways, either using a garden hose from a nearby faucet or plumbing with hot and cold water as with fixtures in your home.

- To use a garden hose, run a garden hose from a faucet and attach to the inlet on the back of your shower. Once the water is turned on you can operate your shower with the control on the inside of the shower. Because you are only plumbing to one of the inlets, the shower will only operate in either the left or right position, depending on which inlet is being used.
- To use hot and cold water you can either run another garden hose to the second inlet or consult a plumber for the best way to bring water to the shower.
- If you find any drips or leaks in any of the fittings, simply locate the source and tighten the fitting with a wrench. Be sure to check that the rubber seal is properly in place and thread tape is used before re-tightening any fittings.

In the Months and Years Ahead...

- We use red cedar for your shower because red cedar is naturally resistant to the effects of weather and moisture. Over time you will see the red cedar turn a silvery-gray as a result of UV exposure. This in no way hurts the lumber, and the natural weathering of the wood adds charm to the shower over time. If you wish to retain the original color of the wood and minimize the effects of UV, you can stain the lumber with a UV-inhibited stain of your choice.
- To clean the wood or bring back the original color you can use a pressure washer in the same way you would clean a wooden deck. Be sure to use a wide pattern and keep a distance from the wood as it is easy to damage the soft cedar with too much pressure.
- Fully drain the shower and remove wand, hose and showhead fixture in freezing temperatures.



1. Place bottom edge of mounting board 42" from ground or floor.



2. Check that mounting board is level and perpendicular to ground or floor.



3. Screw mounting board to surface using 3" screws.



4. Fit shower mount over mounting board as shown.



5. Screw shower mount to mounting board on both sides using 2" screws.



6. Twist rain shower head onto shower stem as shown.



7. Attach hand wand hose to shower fixture as shown.

Your Wall Shower is now ready to hook up to a garden hose. Connect a garden hose to the fitting on the rear of the shower and turn on the water. If adding hot water via a garden hose simply remove the cap on the other rear fitting and attach the included swivel fitting. If having a plumber connect hot and cold directly to the shower simply remove the hose fittings and connect directly to the shower.