

Import Vehicles	Top of Shift stick Diameter and Pitch	Adapter Part Number
Acura Manual	10mm x 1.5mm	KNOBINR2002
Audi Manual	12mm x 1.5mm	KNOBINR2016
Honda Manual	10mm x 1.5mm	KNOBINR2002
Mazda Automatic	8mm x 1.25mm	KNOBINR2015
Mazda Manual including Miata	10mm x 1.25mm	KNOBINR2009
Mazda Manual RX7 1988 thru 1992	12mm x 1.5mm	KNOBINR2016
Mitsubishi Manual Transmissions	10mm x 1.25mm	KNOBINR2009
Subaru Automatic Transmissions	10mm x 1.25mm	KNOBINR2009
Subaru Manual Transmissions	12mm x 1.25mm	KNOBINR2010
Toyota Automatic Transmissions (most)	8mm x 1.25mm	KNOBINR2015
Toyota Manual Transmissions (most)	12mm x 1.25mm	KNOBINR2010
Toyota Tacoma and Tundra Trucks	12mm x 1.25mm	KNOBINR2010
Volkswagon Beetle 1964-1968	7mm x 1mm	KNOBINR2014
Volkswagon Beetle 1968 and newer	12mm x 1.5mm	KNOBINR2016
Volkswagon Ghia 1968 and newer	12mm x 1.5mm	KNOBINR2016
Volkswagon Golf	12mm x 1.5mm	KNOBINR2016
Volkswagon Jetta	12mm x 1.5mm	KNOBINR2016
Volkswagon Rabbit	12mm x 1.5mm	KNOBINR2016
Volkswagon Vanagon Pre-1985	12mm x 1.5mm	KNOBINR2016

US Vehicles	Top of Shift stick Diameter and Pitch	Adapter Part Number
Chevrolet Camaro Manual 1967 to 1969	5/16" - 18	KNOBINR2006
Chevrolet Camaro Manual 1970 to 1981	3/8" - 16	KNOBINR2004
Chevrolet Camaro Manual 1982 to 2002	16mm x 1.5mm	No Adapter Needed
Chevrolet Camaro Manual Non-Threaded	Measure and order correct Lo-Dapt or contact us	
Chevrolet Chevelle Manual	9/16" - 18	N/A
Chevrolet Corvair Manual up to 1963	5/16" - 18	KNOBINR2006
Chevrolet Chevy II/Nova Manual	9/16" - 18	N/A
Chevy Nova Manual 1972	1/2" - 20	KNOBINR2001
Chevrolet Truck Manual 1936-1946	3/8" - 24	KNOBINR2005
Chevrolet Older Models Manual "1950's"	3/8" - 24	KNOBINR2005
Chevrolet Corvette Manual (Most Models up to 2004 please verify)	9/16" - 18	N/A
Dodge Ram Cummins Manual (Most Models please verify)	10mm x 1.5mm	KNOBINR2002
Dodge Dart Manual up to 1976	3/8" - 24	KNOBINR2005
Dodge Dakota Manual	10mm x 1.5mm	KNOBINR2002
Dodge Manual 1940's & 1950's (Most Models, please verify)	5/16" - 24	KNOBINR2007
Dodge Viper Manual	1/2" - 20	KNOBINR2001
Ford F150 Manual Non-Threaded	Measure and order correct Lo-Dapt or contact us	
Ford Fairlane & Falcon	1/2" - 20	KNOBINR2001
Ford Focus & Fiesta & GT (Most Models, please verify)	12mm x 1.25mm	KNOBINR2010
Ford Model A most older Ford Cars and Trucks	5/16" - 24	KNOBINR2007
Ford Mustang 1964-1969 (Most Models, please verify)	1/2" - 20	KNOBINR2001
Ford Mustang 1979-2004 (Most Models, please verify)	12mm x 1.75mm	KNOBINR2003
Ford Probe Manual	10mm x 1.25mm	KNOBINR2009
Ford Escort LX Manual	10mm x 1.25mm	KNOBINR2009
Jeep CJ5/CJ6/CJ7/CJ8 & Scrambler 1955 to 1986 Manual (Please verify, some are 3/8" - 16 depending on transmission)	3/8" - 24	KNOBINR2005
Jeep Wrangler YJ Manual 1987-1995	3/8" - 16	KNOBINR2004
Jeep Wrangler TJ & Unlimited Manual 1997-2006	10mm x 1.5mm	KNOBINR2002
Pontiac Fiero Manual	16mm x 1.5mm	No Adapter Needed
Pontiac Firebird Manual 1967 to 1968	5/16" - 18	KNOBINR2006
Pontiac Firebird Manual 1070 to 1981	3/8" - 16	KNOBINR2004
Pontiac Firebird Manual 1982 to 2002	16mm x 1.5mm	No Adapter Needed
Chrysler PT Cruiser Manual	3/8" - 16	KNOBINR2004

<b>Motorcycles</b>	<b>Top of Shift stick Diameter and Pitch</b>	<b>Adapter Part Number</b>
Harley Davidson (Most models please verify)	3/8" - 24	KNOBINR2005
Indian (Most most models please verify)	3/8" - 24	KNOBINR2005

<b>Aftermarket Shifters</b>	<b>Top of Shift stick Diameter and Pitch</b>	<b>Adapter Part Number</b>
Hurst sticks (Most models please verify)	3/8" - 16	KNOBINR2004
Lokar (Most models please verify)	3/8" - 16 or 3/8" - 24	KNOBINR2004 or KNOBINR2005
B&M (Most models please verify)	1/2" - 20	KNOBINR2001
Gennie Stainless Steel Sticks	5/16" - 18	KNOBINR2006
Gennie Commander Aluminum Sticks	7/16" - 20	KNOBINR2012
Gennie Lo-Dapt	3/8" - 16	KNOBINR2004
Gennie Lo-Dapt II	16mm x 1.5mm	No Adapter Needed
Gennie Lo-Dapt III	16mm x 1.5mm	No Adapter Needed
Gennie Brodie Knob adapter	16mm x 1.5mm	No Adapter Needed